
Ultimate Lite Astragal Flush Bolt


Replacement Instructions






Note: These bolts are compatible as <u>upper bolts</u> for 6'8" astragals **only** and <u>lower bolts</u> for both 6'8" and 8'0" astragals.


Product Reference Guide




STEP 1: REMOVE THE INACTIVE DOOR PANEL FROM THE JAMB



a. Open both door panels to access the hinges of the inactive door panel.




b. Remove the screws securing the inactive door to the hinges.




c. Place the door panel horizontally against a strong support to access the astragal.


STEP 2: REMOVE THE OLD BOLT FROM THE ASTRAGAL BODY



a. Remove the trim strip covering the bolt being replaced.




b. Remove the screws securing the bolt into the astragal body and door panel and set aside.




c. Slide the bolt out of the astragal and discard.

STEP 3: INSTALL NEW BOLT




a. Slide the new bolt into the astragal body until the end of the bolt sleeve is flush with the end of the astragal.




c. Insert screws into the holes on the bolt sleeve and finger notch housing that are aligned with the holes in the astragal body. Tighten so the surface of the screw is just flush with the surface of the bolt.



You should install a total of **4** screws if replacing the upper bolt or **2** screws if replacing the bottom bolt.




b. If the holes on the bolt do not align with the holes in the astragal body, adjust the location of the bolt sleeve and/or finger notch housing to align the holes. The bolt sleeve may be up to 1/4" inset from the end of the astragal.



NOTE: If replacing the lower bolt, install a new corner pad (purchased separately) at this step.


Corner pads should be installed flush against the bottom pad and tucked under the weatherstrip.

STEP 4: CHECK BOLT OPERATION




a. To check bolt operation, press down on the finger notch and push the bolt out towards the end of the astragal. To unlock the bolt, press down and slide back.


For Upper Bolt Only: If retracting the bolt is tight, loosen the screws on the upper bolt sleeve.




STEP 5: REINSTALL THE DOOR PANEL



a. Replace the trim strip previously removed from the astragal body.



b. Reinstall the inactive door panel by screwing the door panel back to the hinges.



c. Close the inactive door and lock the bolts to ensure the bolts contact the header and sill receivers properly.

