

December 1st, 2014

## Wood Veneer Ultimate Astragal Repair Instructions

1. Lightly sand damaged area with 220 grit paper to smooth out bumps and burs.



2. Apply "DAP Plastic Wood" brand repair filler to damaged area. Follow container instructions.



3. Finish wood veneer for exterior use.



DAP® Plastic Wood®		
Veneer Species	DAP Color	UPC No.
Alder	Natural	7079821502
Fir	Pine	7079821404
Mahogany	Walnut	7079821434
Oak	Light Oak	7079821400
Pine	Pine	7079821404



- Other wood fillers may work, but require evaluation by the user.

U.S. Patents: 5, 857, 291; 6, 491, 326; 8,157,298; 8,157,299

The information contained in this document is the confidential and proprietary information and trade secrets of Endura Products, Inc. Any disclosure, use or dissemination of such information without the express written permission of Endura Products, Inc. is strictly prohibited. Endura Products, Inc. also owns any and all intellectual property rights embodied in such information, including patent rights, copyrights, and trademark rights, and no license of any intellectual property right is intended, nor should any license be implied, as a result of the receipt of this document.

 **Endura**®

PERFORMANCE STANDARD

8817 W. Market St., Colfax, NC 27235  
**1.800.334.2006** [www.enduraproducts.com](http://www.enduraproducts.com)