

Repainting FrameSaver® Composite Frame Section

MATERIALS REQUIRED:

- Sandpaper
- Clean, dry cloth
- High Grade Exterior Oil-Based/Alkyd Primer
- High Quality Exterior Acrylic House Paint

PROCESS:

1. Sand off any existing paint from the area down to the raw composite material, and wipe clean with a dry cloth.
2. Prime the section with one coat of a high grade exterior oil-based/alkyd primer.
3. Allow primer to dry according to the manufacturer's instructions - usually 36-48 hours depending on weather conditions and temperature (cold/damp conditions will require longer drying time).
4. Paint the area with a high quality exterior acrylic house paint.