

Field Refinishing of Frames

Displaying Mold Spotting

TOOLS REQUIRED:

- Sandpaper (course and fine)
- Concrobium Mold Control
- Exterior, Mold Killing Primer (such as Kilz Complete or Zinsser Mold Killing Primer)
- Exterior House Paint (recommended: All-Acrylic, Semi-Gloss Enamel)
- Cloth for Cleaning

PROCESS:

1. Sand the affected area to bare wood or composite, using course sandpaper.
2. Apply Concrobium Mold Control to sanded area per label instruction. **LET DRY FOR 24 HOURS.**
3. Once the area is fully dry, reprime and repaint as follows:
 - a. Apply an exterior, mold killing primer, such as Kilz Complete or Zinsser Mold Killing Primer.
 - b. Follow application and drying instructions found on the label.
 - c. Prepare the primed surface for topcoating by lightly sanding with 400 grit or finer sandpaper.
 - d. Wipe the sanded surface clean before painting.
 - e. Apply two coats of an exterior house paint, following label instructions. An **All-Acrylic, Semi-Gloss Enamel** is recommended.