

# Reinforcing Strike Kits for Trilennium® Multi- Point Locks

## Installation Instructions



### Tools Required:



Phillips  
Screwdriver



The jambs should already be routed for these strike plates.

1. Attach the dust box to the reinforcing plate.
  - a. The dust box feet should align with the slots in the reinforcing plate.
  - b. The reinforcing plate arms should sit inside the dust box.
2. Align the three holes on the strike plate with the reinforcing plate.
3. Use 3/4" screws in the top and bottom holes of each strike.
4. Use long #10 x 2-1/2" screw in center hole (The purpose is to anchor each strike plate to the structural framing for added security)
5. Repeat for the remaining strike locations.

