

Adjusting the W & F Template Router Carrier

Loosen the cap screws holding the side plates with a 3/16" allen wrench. Pull the side plate out and orient it as desired. Line up the ribs with the proper groove and reinsert the side plate. Retighten the cap screws. Repeat this process for the other side.

Note: On 1 3/4" thick doors the fabrication must be centered with both sides adjusted to the same position. On thicker doors you can offset the fabrication by adjusting the side plates to different positions as required.

