


ASTRAGAL OPTION SELECTION GUIDE

FINISH SELECTION




SWING AND HANDING SELECTION

LEFT HAND INSWING




When you stand with your back against the hinges of the active (moving) door panel, if the door opens to the left and swings into the house, you need a LEFT HAND INSWING ASTRAGAL.

RIGHT HAND INSWING




When you stand with your back against the hinges of the active (moving) door panel, if the door opens to the right and swings into the house, you need a RIGHT HAND INSWING ASTRAGAL.

LEFT HAND OUTSWING



When you stand with your back against the hinges of the active (moving) door panel, if the door opens to the left and swings out of the house, you need a LEFT HAND OUTSWING ASTRAGAL.

RIGHT HAND OUTSWING



When you stand with your back against the hinges of the active (moving) door panel, if the door opens to the right and swings out of the house, you need a RIGHT HAND OUTSWING ASTRAGAL.

**Astragals should be ordered based on the handing and swing of the active (moving) door panel. **

