







# ENDURA ULTIMATE MULTI-POINT ASTRAGAL: SHOOT BOLT SELECTION GUIDE

Shoot bolts on the Ultimate Multi-Point Astragal are handed and depending on the handing of your French Door, you will need either a Left-handed or Right-handed bolt. See guide below to identify the swing and handing of your door.







**NOTE:** For both inswing and outswing doors, the handing of the top bolt **matches** the handing of the astragal. The handing of the bottom bolt is **opposite** to the handing of the astragal.

## IDENTIFY HANDING OF ASTRAGAL

## CHOOSE COMPATIBLE SHOOT BOLT

<b>INSWING</b>				
	<b>OUTSWING</b>			*matches handing of astragal

When you stand with your back against the hinges of the active (moving) door panel, if the door opens to your **left**, you have a **LEFT HANDED ASTRAGAL**.

<b>INSWING</b>				
	<b>OUTSWING</b>			*matches handing of astragal

When you stand with your back against the hinges of the active (moving) door panel, if the door opens to your **right**, you have a **RIGHT HANDED ASTRAGAL**.

