


**TRILENNIUM® HANDSETS**  
Handle Functions

Type of Trilennium® Handset	Interior of Door		Exterior of Door	
	Does it have a Thumb-Turn?	Type of Lever	Does it have a Key Cylinder?	Type of Lever
Active for 3000/3070/3500 Locks	Yes	Operational*	Yes	Operational
Thumb-Turn Drive for 3020 Lock	Yes	Fixed**	No	Fixed
Dummy	No	Fixed	No	Fixed

\* Operational Lever: Can move up and down when door is unlocked.  
 \*\* Fixed Lever: Inactive, and is intended for push/pull function.


**IDENTIFY THE ACTIVE TRILENNIUM HANDSET COMPONENTS**



## HANDSET HANDING





Before you buy a Trilennium Eclipse Grip handset, an Emtek Handset, or a Rocky Mountain Hardware Handset, determine whether you need a left hand or right hand handset. Here's how:

- Stand outside your home.
- Look at your door panel (active panel for French doors) and determine which side your hinges are.
- For hinges on the right, you will need a Right Handed Handset
- For hinges on the left, you will need a Left Handed Handset



*Trilennium Eclipse Grip Handset Shown*

### RIGHT HANDED HANDSET



### LEFT HANDED HANDSET

