

FrameSaver® FusionFrame™

Cleaning Instructions

GENERAL NOTES:

- FusionFrame products with a top coating applied should be cleaned according to the coating manufacturer's instructions.
- Instructions below apply to FusionFrame products without a coating.

CLEANING:

- Use mild soap and water to remove dust, dirt, oil, grease and other contaminants.
- Use 100% mineral spirits applied to a clean cloth for scuff marks and blemishes that cannot be removed with soap and water.

CAUTION:

- DO NOT use sandpaper or steel wool on the frame surface.
- DO NOT use scouring pads or other abrasive cleaners on the frame surface.
- DO NOT use acetone, MEK or similar chemicals on the frame surface.

MAINTENANCE:

Frames should be inspected annually to determine condition of the coating. Refinishing of the clear protective coating should be conducted as needed or per the coating manufacturer's recommendations. Any signs of blistering, peeling or cracking the finish should be immediately repaired. Failure to properly maintain the topcoat will result in further coating degradation.

DISCLAIMER:

- Endura cannot be responsible for cleaning methods not following these recommendations.

